

Getting started with the BJOY Ring wireless


Step
1

Charge the battery using the micro USB cable provided until the battery LED (red) stops flashing. Disconnect the cable.



Step
2

Assembly all the parts of the equipment following the instructions of the Quick Start Guide.



Step
3

Connect the receiver to the USB port of the device that you wish to control. (It is possible to connect up to 4 receivers)




Step
4

If using the device for first time **press the reset button** in the transmitter to activate it. **Do not move the joystick while the device is beeping.**



Step
5

Calibrate the device using the BJOY software. Install the program in a Windows PC and follow the instructions of the calibration menu to perform the calibration.



Step
6

Customise the device operation using the BJOY software. Check the Help menu for instructions.

How to shut down the device

There are different ways to shut down the device:

1

Enabling the **option to shut down with a switch press** in the “shutdown” menu of the configuration program. Choose Switch A or B and set the Shut down accept time.

2


Using the **button “Shut down now”** in the BJOY software.

3

Enabling the option to enter the sleep mode after several minutes idle. Configure the inactivity time to enter the sleep mode.

4

If there are **no receivers in the coverage range** and the time to enter the sleep mode is enabled, the device will deactivate automatically after the inactivity time.




How to activate the device

There are two possible ways to activate the device:

1

Making a gesture with the joystick: move the joystick through the 4 cardinal points (N, E, S, W) during 0.5 to 3 sec.



2

By a switch press: plug the switch into any switch input (A or B) and press the switch.



Getting started with the BJOY Ring wireless

Step
1

Charge the battery using the micro USB cable provided until the battery LED (red) stops flashing. Disconnect the cable.



Step
2

Assembly all the parts of the equipment following the instructions of the Quick Start Guide.



Step
3

Connect the receiver to the USB port of the device that you wish to control. (It is possible to connect up to 4 receivers)




Step
4

If using the device for first time **press the reset button** in the transmitter to activate it. **Do not move the joystick while the device is beeping.**



Step
5

Calibrate the device using the BJOY software. Install the program in a Windows PC and follow the instructions of the calibration menu to perform the calibration.



Step
6

Customise the device operation using the BJOY software. Check the Help menu for instructions.

How to shut down the device

There are different ways to shut down the device:

1

Enabling the **option to shut down with a switch press** in the “shutdown” menu of the configuration program. Choose Switch A or B and set the Shut down accept time.

2


Using the **button “Shut down now”** in the BJOY software.

3

Enabling the option to enter the sleep mode after several minutes idle. Configure the inactivity time to enter the sleep mode.

4

If there are **no receivers in the coverage range** and the time to enter the sleep mode is enabled, the device will deactivate automatically after the inactivity time.




How to activate the device

There are two possible ways to activate the device:

1

Making a gesture with the joystick: move the joystick through the 4 cardinal points (N, E, S, W) during 0.5 to 3 sec.



2

By a switch press: plug the switch into any switch input (A or B) and press the switch.

