





①

Take off handpad.
Turn **TiPY™** so **ESC** is at the top right corner.




②

Remove protective foil from battery compartment.



③

Connect **TiPY™** to your computer using the USB-C cable provided.
ESC lights up **red**. **ESC** flashes **red** while charging. Battery is pre-charged.



Getting started with

TiPY™




Press **Fn** + **+** .
Fn flashes fast in **green**. Then press ...

... **P↓** **for Apple products.**
The LED on the handpad lights up **green**. ●

... **P↑** **for Windows, Linux or Android products.**
The LED on the handpad is off. ○

Choosing the
Operating System



Press **[Fn] + []**.

[Fn] flashes fast in **green**.

For the desired language now press:


- | | | |
|-------------------------|----------------------------|-----------------------------|
| [D] + [E] German | [E] + [N] English | [E] + [S] Spanish |
| [F] + [R] French | [I] + [T] Italian | [P] + [T] Portuguese |
| [N] + [L] Dutch | [S] + [V] Swedish | [F] + [I] Finnish |
| [D] + [A] Danish | [N] + [O] Norwegian | [I] + [S] Icelandic |

Depending on the language chosen, the four **blue** LEDs  on the handpad light up in a certain pattern (see label on the handpad).

Choosing the Language




Connect through USB-C



Connect **TiPY™** to your computer using the USB-C cable provided.
(ESC) lights up **red**. **TiPY™** is connected to your computer and will charge if necessary ((ESC) flashes **red**).



Connect through Bluetooth



Disconnect USB-C cable. (Fn) flashes **green**. Without cable, **TiPY™** automatically searches for a Bluetooth connection. Wait for your computer to find the new Bluetooth device. Follow the instructions on the screen to pair **TiPY™** with your computer. When connected, (Fn) lights up **green**.

In case of Bluetooth interferences, (Fn) flashes very fast. In this case, remove the Bluetooth device from your computer and pair it again. The **TiPY™** Bluetooth connection can only be removed from the computer the device is connected to.

Connect
TiPY™
to your computer

After some time of inactivity, **TiPY™** enters standby mode, then sleep mode.
Press any key to wake **TiPY™** from standby or sleep mode.
[ESC] flashes **red** when battery is low.

Both left-handers and right-handers can use **TiPY™**. In order to switch sides, take off the handpad, turn the keyboard around, and put the handpad back on. **TiPY™** automatically detects which side is in use and deactivates the bottom side. The mouse joystick is always located on the thumb's side.



Left-handed use



Right-handed use



Press **[NUM]** to activate or deactivate the number pad. When activated, the key lights up **blue**.

Good to know


TiPY™



The mouse is operated by using the mouse joystick and the adjacent keys  for left click,  for right click, and  for scrolling.

TiPY™

Mouse Function



TiPY™ Trainer, free to use on
tipykeyboard.com



TiPY™